


# Building the QuickBot

Control of Mobile Robots: Hardware Lecture #2






Rowland O'Flaherty
Robotics Ph.D. Candidate
Georgia Tech





### Solder Header Pins Onto Encoder Board



- Encoder Board
- Header Pins




Solder Header

#### Top View




#### **Bottom View**






## Attach Encoder Board to Bottom Chassis Plate



- Bottom Chassis Plate
- One Encoder board
- Two 1/2" 4-40 Screws
- Four 4-40 Nuts






Nuts are on both sides of the encoder board








# Attach Right Motor



- Bottom Plate Assembly
- One Motor
- Two Motor holders
- Two M3\*30 Screws
- Two M3 Nuts







Note: Small knob on the side of the motor faces the outside of the robot Black wire is close to the chassis board, red wire is away from chassis board




#### Attach Left Motor



- Bottom Plate Assembly
- One Motor
- Two Motor holders
- Two M3\*30 Screws
- Two M3 Nuts







Note: Small knob on the side of the motor faces the outside of the robot Black wires are close to the chassis board, red wire away from chassis board



## Attach Omni Wheel




- Bottom Plate Assembly
- One Omni Wheel
- Four M3\*6 Screws
- Two L25 Spacers




#### Top View



#### **Bottom View**




Side View






#### Attach Wheels and Encoder Discs




- Bottom Plate Assembly
- Two Wheels
- Two Encoder Discs








#### Attach Breadboards




- Bottom Plate Assembly
- One Small Breadboard
- One Medium Breadboard









#### **Attach Chassis Standoffs**



- Bottom Plate Assembly
- Four M3\*6 Screws
- Four L25 Spacers







## Attach BBB Standoffs



- Top Plate Assembly
- Four M3\*6 Screws
- Four L10 Spacers












# Attach Battery Holders



- Top Plates Assembly
- Two Battery Holders
- Two M3\*10 Screws
- Two M3 Nuts
- Two 1/4" 4-40 Screws
- Two 4-40 Nuts










#### Assemble IR Sensors



- IR Sensor
- Two 1/4" 4-40 Screws
- Two 4-40 Angle Bracket




Note: Leave very loose, don't tighten yet




Repeat 5 times!





# Attach Two Lower IR Sensors Top View



- Bottom Plate Assembly
- Two IR Assemblies
- Four ½" 4-40 Screws
- Four 4-40 Nuts












# Attach Three Upper IR Sensors




- Top Plate Assembly
- Three IR Assemblies
- Six 1/2" 4-40 Screws
- Six 4-40 Nuts









## Attach Top Plate Assembly to Bottom Plate Assembly



- Top Plate Assembly
- Bottom Plate Assembly
- Four M3\*6 Screws











# Attach BeagleBone Black



- Robot Assembly
- BeagleBone Black
- Four M3\*6 Screws







## All Done!

